



## BRUSHED METAL

Step 1. Follow Best Demonstrated Practices for the type of substrate you are working on to provide a high quality undercoat system.

Step 2. Mix U7208 medium bright metallic basecoat at a ratio of 1 to 1 with PCS15 Advanced Integrated Fast Stabilizer Apply 2 to 3 coats or until hiding is achieved.

Allow Basecoat Color to dry 30 minutes.

Step 3. With light pressure, scuff sand Basecoat Color with a gray nylon scuff pad.

Carefully sanding in one direction will produce a Brushed Metal appearance. Sanding can be random for a different look.

Many different patterns can be achieved with this technique

Step 4. Carefully blow and tack off surface. Apply 2 coats of any Ultra Clearcoat

